

DESCRIPTION and USES

RepcoLite's Carefree Interior Wall Finishes are high quality products designed for those who desire the finest in interior wall paints. Paints with the Carefree label provide the user with the following benefits: Easy, no-splatter application, one coat coverage on most surfaces, a durable, washable surface suitable for most interior wall, ceiling, or trim surfaces. Carefree Interior Wall Finishes may be used as a primer and paint all in one, but in certain situations, the use of a primer is recommended to achieve maximum performance. Carefree finishes are available in 4 sheens: Flat, Eggshell Enamel, Satin Sheen Enamel, and Semi-Gloss Enamel.

SURFACE PREPARATION

All surfaces to be painted must be clean, free from dirt, oil, and other surface contamination. It is always best to wash all surfaces with a household detergent solution before painting. Rinse the surface to remove detergent residue. Sand all glossy, alkyd enamel surfaces with #150 sandpaper and wipe clean. Patch all holes and cracks with a suitable patching material.

APPLICATION

Stir well! Apply full, wet coats with a brush, roller, or airless spray equipment. Apply at a rate of 400 – 450 square feet per gallon. Rough or textured surfaces will require more paint. Allow 3 – 4 hours dry time before recoating. Thin only when necessary with small amounts of water.

CLEAN UP

Clean painting tools immediately after use with warm, soapy water. Wipe up spill before they dry with a damp cloth.

SAFETY INFORMATION

For complete safety information, refer to the Safety Data Sheet for this product.

The suggestions for use and technical data here given are accurate to the best of our knowledge and are offered in good faith. Because the conditions and use of our products are beyond our control, our liability, if any, is limited to the replacement of defective material only. RepcoLite Paints, Inc. DISCLAIMS ALL OTHER WARRANTIES relating to our products and DISCLAIMS ALL WARRANTIES RELATING TO THEIR APPLICATION, expressed or implied, INCLUDING but not limited to warranties of merchantability and fitness for a particular purpose. TECHNICAL DATA IS SUBJECT TO CHANGE WITHOUT NOTICE.

TECHNICAL DATA

Finish:	Eggshell (60° Gloss 5 – 10)
Vehicle Type:	Vinyl Acrylic Latex
Volume Solids:	36%
Coverage:	400 – 450 SF/Gallon
Dry Time:	
<i>Touch:</i>	30 – 60 Minutes
<i>Recoat:</i>	4 – 6 Hours (dry times will be extended by colorant addition and/or high humidity).
Primer:	
<i>Drywall:</i>	44410 Quick Sealer
<i>Plaster:</i>	44110 Prime-All 44010 Pro-Flo Primer-Undercoater
<i>Metal:</i>	44917 Metl-Clad Metal Primer
<i>Ferrous Metals:</i>	44210 Zip Prime
<i>Wood:</i>	44010 Pro-Flo Primer-Undercoater
VOC:	Less than 150 g/L
Clean Up:	Water

PRODUCT CODE INFORMATION

42110	Carefree Eggshell—White
42102	Carefree Eggshell—272 Base
42103	Carefree Eggshell—273 Base
42106	Carefree Eggshell—276 Base

RepcoLite Paints, Inc.

473 W. 17th St.

Holland, MI 49423

(616) 396-1275

www.repcolite.com